


DIAGRAM OF GG-1



| Key No. | Description | Part number | QTY | Key No. | Description | Part number | QTY |
|---------|----------------|-------------|-----|---------|----------------|-------------|-----|
| 1. | Screw | 351-0922 | 4 | 15. | Rubber Valve | 351-0936 | 1 |
| 2. | Finger Grip | 351-0923 | 1 | 16. | Piston Rod | 351-0937 | 1 |
| 3. | O-ring | 351-0924 | 2 | 17. | Plunger Lock | 351-0938 | 1 |
| 4. | Bump | 351-0925 | 1 | 18. | Plunger | 351-0939 | 1 |
| 5. | Spring | 351-0926 | 1 | 19. | Washer | 351-0940 | 1 |
| 6. | Spring | 351-0927 | 1 | 20. | Long Spring | 351-0941 | 1 |
| 7. | Filler Plug | 351-0928 | 1 | 21. | Air Inlet | 351-0942 | 1 |
| 8. | Air Vent Valve | 351-0929 | 1 | 22. | Switch | 351-0943 | 1 |
| 9. | Ball | 351-0930 | 1 | 23. | Pin | 351-0944 | 1 |
| 10. | Spring | 351-0931 | 1 | 24. | Trigger | 351-0945 | 1 |
| 11. | Adapter | 351-0932 | 1 | 25. | Container Tube | 351-0946 | 1 |
| 12. | Housing Cap | 351-0933 | 1 | 26. | End Cap | 351-0947 | 1 |
| 13. | Gasket | 351-0934 | 1 | 27. | Handle | 351-0948 | 1 |
| 14. | Piston Set | 351-0935 | 1 | 28. | Hex Spout | 351-0949 | 1 |