


DIAGRAM OF IW-3A93



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
101	12227-0070011-1	ANVIL UNIT	405	12226-0074701-1	TIP VALVE			
102	1230B-0070001-1	HAMMER FRAME PIN	406	12308-0070009-1	SPRING			
103	1230C-0070001-1	HAMMER	408	12346-0134702-1	DEFLECTOR			
104	1230E-0100001-1	HAMMER FRAME	409	12309-0014701-2	AIR INLET			
201	12201-0076609-1	HOUSING						
202	1230N-0134703-1	HANDLE GRIP						
203	1230K-0070018-1	HAMMER CASE BUSHING						
204	1231V-0100001-1	STEEL RING						
205	2041105-01040-1	O - RING						
206	1230L-0074712-1	REVERSE VALVE						
207	2041109-01030-0	O - RING						
208	2040202-08010-0	FLAT WASHER						
209	2041108-01150-0	O - RING						
210	1230S-0070015-1	REAR COVER GASKET						
211	12394-0071303-1	REAR COVER						
212	1233B-0134701-1	REGULATOR						
213	1230J-0150002-3	POSITIONING SPRING						
214	2040800-05020-0	BALL						
215	2040101-03110-2	HEX.SOC.HD.BOLT						
301	2041200-00054-0	BEARING						
302	2042300-04080-0	OIL SEAL						
303	12312-0070009-1	FRONT BEARING PLATE						
304	12315-0070012-1	CYLINDER						
305	2040400-03030-0	SPRING PIN						
306	12314-0070008-1	BLADES						
307	12313-0070008-1	ROTOR						
308	12316-0070006-1	REAR END PLATE						
309	2041200-00088-0	BEARING						
310	1230B-0074701-1	PIN						
401	12225-0074705-1	TRIGGER UNIT						
402	2040400-03100-0	SPRING PIN						
403	12319-0070001-3	SEAL						
404	1230K-0070007-3	BUSHING						